
Radio C1



Connector Part Information

• OEM: 12110206

24-Way F Micro-Pack 100 Series (L-BU)

		24-Way F Micro-Pack 100 Series (L-BU)				
Pin	Wire Color	Circuit No.	Function			
A1	GY	118	Left Front Speaker Signal (-) (1) (U1C)			
A1	D-GN	1947	Left Front Low Level Audio (-) (US8)			
A2	TN	201	Left Front Speaker (+) (1) (U1C)			
A2	TN	511	Left Front Low Level Audio Signal (US8)			
A3	L-BU	115	Right Rear Speaker Signal (-) (U1C)			
A3	TN	1946	Right Rear Low Level Audio (-) (US8)			
A4	D-BU	46	Right Rear Speaker (+) (U1C)			
A4	D-BU	546	Right Rear Low Level Audio Signal (US8)			
A5	BN	199	Left Rear Speaker (+) (U1C)			
A5	BN/WH	599	Left Rear Low Level Audio Signal (US8)			
A6	YE	116	Left Rear Speaker Signal (-) (U1C)			
A6	BN	1999	Left Rear Low Level Audio (-) (US8)			
A7	L-GN	200	Right Front Speaker (+) (1) (U1C)			
A7	L-GN/WH	512	Right Front Low Level Audio Signal (US8)			
A8	D-GN	117	Right Front Speaker Signal (-) (1) (U1C)			
A8	L-GN	1948	Right Front Low Level Audio (-) (US8)			
A9	D-BU	1796	Steering Column Radio Control Signal (UK3)			
A10	WH/BK	644	10-Volt Reference (US8)			
A11			Not Used			
A12	BK/WH	1051	Signal Ground			
B1	RD/WH	1140	Battery Positive Voltage			
B2	8**		Not Used			
В3	L-GN	1011	Remote Radio Control Signal (US8)			
B4-B5	120	1 24	Not Used			
B6	PK	314	Radio On Signal			
B7-B8	8***		Not Used			
B9	D-GN	5060	Low Speed GMLAN Serial Data			
B10-B12	(A)		Not Used			

Co	m	n	0	n	er	nts
00		۲	v		CI	110

Car Radio Battery Constant 12V+ Wire

Car Radio Accessory Switched 12V+ Wire

Car Radio Ground Wire

Car Radio Illumination Wire

Car Radio Dimmer Wirez diagram.co

Left Front Speaker Positive Wire (+)

Left Front Speaker Negative Wire (-)

Right Front Speaker Positive Wire (+)

Right Front Speaker Negative Wire (-)


Left Rear Speaker Positive Wire (+)

Left Rear Speaker Negative Wire (-)


Right Rear Speaker Positive Wire (+)

Right Rear Speaker Negative Wire (-)

REAR VIEW AND CONNECTORS




<CN702 12P CONNECTOR>



- 1. Audio Right (+)
- 2. Audio Left (+)
- 3. Signal Ground
- 4. Mute
- 5. Power Supply, +B
- 6. Audio Right (-)
- 7. Audio Left (-)
- 8. Ground
- 9. Communication TX (-)
- 10. Communication TX (+)
- 11.
- 12. Power Supply, ACC

REAR VIEW AND CONNECTORS



Components	c
Car Radio Battery Constant 12V+ Wire	
Car Radio Accessory Switched 12V+ Wire	
Car Radio Ground Wire	
Car Radio Illumination Wire	
Car Radio Antenna Trigger Wire	
Car Audio Front Tweeter Size	
Car Audio Front Tweeter Depth	-
Left Front Speaker Positive Wire (+)	
Left Front Speaker Negative Wire (-)	
Right Front Speaker Positive Wire (+)	
Right Front Speaker Negative Wire (-)	
Car Audio Front Speakers Size	6
Car Audio Front Speakers Depth	
Left Rear Speaker Positive Wire (+)	
Left Rear Speaker Negative Wire (-)	
Right Rear Speaker Positive Wire (+)	
Right Rear Speaker Negative Wire (-)	
Car Audio Rear Speakers Size	6

